



BGGRC20HDS

1. You will need to remove the tow hooks in order to install bottom brackets. Remove the tow hooks by removing the 18mm bolts and nuts.



2. Install the bottom brackets by sliding the brackets from the back. The bracket mounts to the outer side of the frame. Reinsert the tow hook and use the 5" x 1/2" bolts to install. If no tow hooks use 1 1/2" x 1/2" bolts. You may have to trim the plastic where the brackets come through the tow hook opening.



3. To install the top brackets, you will need to remove the factory grille. You will need to remove the side panels first. Start by removing the inner fender well screws. This will allow to get to the back side of the plastic clips. There will also be a small screw in the corner that need to be removed before the side panel can be pulled off.

