

HALOGEN FOG LIGHT BRACKET INSTALLATION

1. *Remove fog lights from factory fog light housing. Remove the fog light by removing the adjusting screw and spring. Then the two side clips.*
2. Insert the fog light into the fog light bracket by spreading the bracket out until the round tabs fit into the holes of the bracket. Place the screw through the bottom tab of the bracket and put the spring on the screw and then into the fog light.
3. There is a driver and passenger side bracket.
4. Mount the fog light bracket to the mounting bracket by using hardware provided.
5. Install the fog light mounting bracket to the hole in the mounting bracket. Line up the light through the hole in the skirt and tighten bolt.
6. Plug in wires and then adjust fog lights as needed.

7. *MAKE SURE ALL NUTS AND BOLTS ARE TIGHT!*